

Batteries for Marine and Leisure



Polarity

The top diagram shows the battery pack with a '+' sign on the left and a '-' sign on the right, indicating the positive and negative terminals. The terminals are located on the left and right sides of the pack, with the positive terminal on the left and the negative terminal on the right.

Terminal Type

The bottom diagram shows the terminal types. The positive terminal is labeled "Positive Terminal" and the negative terminal is labeled "Negative Terminal". The dimensions for the terminals are: 3.8 - 18UNC for the positive terminal and 5.18 - 18UNC for the negative terminal. The diameter of the terminal is $\varnothing 17.5$ for the positive terminal and $\varnothing 15.9$ for the negative terminal. The height of the terminal is 17 for both.

1 / 1